Programming Fuji PXR3

1. Hold down SEL key until P-n1 is showing (5 seconds).
2. Set control range
   a. Scroll down to SV-L
   b. Press SEL
   c. Set number to 105
   d. Press SEL
   e. Scroll Down to SV-H
   f. Press SEL
   g. Set number to 150
3. Hold down SEL key until SV light (red) is lit
4. Set number to 120
5. Hold down SEL key until P is showing
6. Press SEL
7. Set number to 0.0
8. Press SEL
9. Scroll down to HYS
   a. Press SEL
   b. Set number to 1
   c. Press SEL
10. Hold down SEL key until SV light (red) is lit
11. Hold down SEL key until PROG is showing
12. Scroll down until LOC is showing
13. Press SEL
14. Scroll up until 5 is showing
15. Hold down SEL until SV (red) light is showing
16. Press SEL again

Once all this has been set, to change upper value (temperature that you want
the grates to shut off at), press SEL and choose new value and press SEL again.